



PL


Tracer Hi-Cube BT RGB Flow 2.1
Instrukcja obsługi

EN


Tracer Hi-Cube BT RGB Flow 2.1
Instructions for use




Tracer Hi-Cube BT RGB Flow 2.1



Tracer Hi-Cube BT RGB Flow 2.1



Tracer Hi-Cube BT RGB Flow 2.1



Ostrzeżenia:

Aby zapewnić bezpieczne i prawidłowe użytkowanie, przeczytaj wszystkie informacje dotyczące bezpieczeństwa przed użyciem urządzenia.

Używaj tylko z bateriami, ładowarkami, akcesoriami i materiałami zatwierdzonymi przez producenta.

- **TO URZĄDZENIE NIE JEST ZABAWKĄ**, NIE pozwalaj dzieciom ani zwierzętom na używanie tych urządzeń lub zabawę nimi.
- Nie demontować, modyfikować ani nie naprawiać urządzeń.
- Nie zanurzać w wodzie.
- Nie wystawiać urządzenia na działanie ekstremalnych temperatur (ciepło lub zimno), otwartego ognia, wilgoci lub wody.
- Unikać obecności kurzu lub wody w okolicy portów USB, gniazda zasilania lub innych wejść urządzenia; unikać kontaktu z przewodnikami, takimi jak płyny, proszki metaliczne itp.

Informacje dotyczące bezpieczeństwa

- Przeczytaj instrukcje.
- Zachowaj tę instrukcję.
- Przestrzegaj wszystkich ostrzeżeń.
- Postępuj zgodnie ze wszystkimi instrukcjami.
- Nie używaj urządzenia w pobliżu wody.
- Czyść wyłącznie suchą szmatką.
- Nie blokuj otworów wentylacyjnych. Zainstaluj zgodnie z instrukcjami producenta.
- Nie ustawiaj urządzenia w pobliżu źródeł ciepła, takich jak kaloryfery, grzejniki, kuchenki lub inne urządzenia (w tym wzmacniacze), które wytwarzają ciepło.
- Nie usuwać zabezpieczeń z wtyczek dwubiegunowych lub wtyczek z uziemieniem. Wtyczka dwubiegunowa ma dwa bolce o różnej grubości. Wtyczka z uziemieniem ma dwa bolce i trzeci styk uziemiający. Szerszy bolec lub trzeci styk mają na celu zapewnienie bezpieczeństwa. Jeśli dostarczona wtyczka nie pasuje do gniazdka, skonsultuj się z elektrykiem w celu wymiany przestarzałego gniazdka.
- Chronić przewód zasilający przed nadepnięciem lub ściśnięciem, szczególnie przy wtyczkach, gniazdach i w miejscach, w których przewody wychodzą z urządzenia.

- Używaj wyłącznie akcesoriów określonych przez producenta.
- Używaj tylko z wózkiem, stojakiem, statywem, wspornikiem lub stołem określonym przez producenta lub sprzedawanym z urządzeniem. Gdy używany jest wózek, należy zachować ostrożność podczas przenoszenia zestawu wózka i urządzenia, aby uniknąć obrażeń spowodowanych przewróceniem. Odłączaj urządzenie od zasilania podczas burzy lub gdy nie jest używane przez dłuższy czas.
- Wszystkie czynności serwisowe należy powierzyć wykwalifikowanemu personelowi serwisowemu. Serwisowanie jest wymagane, gdy urządzenie zostanie w jakikolwiek sposób uszkodzony, np. zostanie uszkodzony przewód zasilający lub wtyczka, do urządzenia dostały się płyny lub ciała obce, urządzenie zostało wystawione na działanie deszczu lub wilgoci, urządzenie nie działa normalnie lub spadło z wysokości.

W opakowaniu

- Subwoofer (1 szt.)
- Głośniki satelitarne (2 szt.)
- Kabel AUX 3,5 mm (1 szt.)
- Instrukcja obsługi (1 szt.)

Opis panelu (rys. 1)

1. Volume – pokrętko głośności
2. Bass – pokrętko basów
3. Port wejściowy AUX 3,5 mm
4. Power – przełącznik zasilania
5. Wskaźnik LED
6. Porty wejściowe głośników satelitarnych
7. Kabel zasilający
8. Wtyczka zasilania AC230V

Podłączanie do portu AUX (rys. 2)

Podłącz jeden koniec dołączonego kabla AUX 3,5 mm do portu wejściowego AUX 3,5 mm z tyłu subwoofera. Podłącz drugi koniec do portu AUX 3,5 mm w urządzeniu do odtwarzania multimedialnych.

Regulacja głośności i basów

W trybie Bluetooth lub AUX możesz ręcznie regulować głośność i basy za pomocą pokręteł z tyłu głośnika lub za pomocą elementów sterujących podłączonego urządzenia.

Włączanie/wyłączanie zasilania

- Użyj przełącznika zasilania [Power] z tyłu subwoofera, aby włączyć i wyłączyć system.
- Po włączeniu system automatycznie połączy się z dowolnym, wcześniej sparowanym urządzeniem Bluetooth, które znajduje się w zasięgu.

Parowanie urządzeń (Bluetooth)

1. Włącz głośnik. Usłyszysz sygnał dźwiękowy, a wskaźnik LED zacznie szybko migać na NIEBIESKO.
2. Rozpocznij wyszukiwanie urządzeń Bluetooth w Twoim urządzeniu mobilnym. Wybierz **TRACER Hi-Cube**, gdy pojawi się na liście znalezionych urządzeń.
3. Po poprawnym sparowaniu urządzeń usłyszysz sygnał dźwiękowy, a wskaźnik LED zaświeci się na NIEBIESKO.

W trybie Bluetooth głośność i basy można kontrolować za pomocą pokręteł głośnika lub elementów sterujących w sparowanym urządzeniu. Wszystkie inne funkcje odtwarzania kontroluje się z poziomu sparowanego urządzenia.

Konfiguracja (rys. 3)

Wybierz lokalizację systemu głośników.

Podłącz jeden z głośników satelitarnych do portu wejściowego głośników satelitarnych L lub R z tyłu subwoofera. Podłącz drugi głośnik satelitarny do drugiego portu.

Podłącz wtyczkę zasilającą subwoofera AC230V do pobliskiego gniazdka ściennego.

Caution

To ensure safe and proper use, read all safety information before using the devices. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with these devices.
- Do not disassemble, modify, or repair the devices.
- Do not submerge in water.
- Do not expose the units to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not allow the USB ports, power jack or other inputs of the devices to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc.

Safety Information

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over. Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or

plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

In the Box

- Subwoofer (x1)
- Satellite Speakers (x2)
- 3.5 mm Aux Cable (x1)
- User Manual (x1)

Location of Controls (fig. 1)

1. Volume Dial
2. Bass Dial
3. 3.5 mm Aux Input Port
4. Power Switch
5. LED Indicator
6. Satellite Speaker Connection Ports
7. Power Cord
8. AC230V Power Plug

Connecting to the Aux Port (fig. 2)

Plug one end of the included 3.5 mm auxiliary cable into the 3.5 mm aux input port on the back of the subwoofer. Plug the other end into the 3.5 mm aux port on your media-playing device.

Adjusting Volume & Bass

In both Bluetooth or AUX mode, you can adjust volume and bass manually with the controls on the back of the speaker, or with the controls on your connected device.

Powering ON/OFF

- Move the [Power] switch on the back of the subwoofer to power the system ON and OFF.
- When powered on, the system will automatically re-pair to any previously-paired Bluetooth device in range.

Bluetooth Pairing

1. Power the speaker ON. A tone will be heard and the LED indicator will quickly flash BLUE.
2. Set your smart device to search for Bluetooth devices. Select **TRACER Hi-Cube** when it appears on the list of found devices.
3. Once successfully paired, a tone will be heard and the LED indicator will turn solid BLUE.

In Bluetooth mode, volume and bass can be controlled with the dials on the speaker or with controls on your paired device. All other playback functions will be controlled by your paired device.

Setting Up (fig. 3)

Choose a location for the speaker system.

Plug one of the satellite speakers' attached connectors into the L or R satellite speaker connection port on the back of the subwoofer. Plug the other satellite speaker's connector into the other port.

Plug the subwoofer's AC230V power plug into a nearby wall socket.





Symbol of electronic and electrical equipment waste (WEEE – Waste Electronic and Electrical Equipment).

Using the WEEE symbol means that this product cannot be treated as household waste. By providing appropriate recycling you help to save the natural environment. In order to get more detailed information about the recycling of this product, contact the local authority representative, waste treatment service provider or the store in which the product has been purchased.



tracer[®]

Producent:
Megabajt Sp. z o.o., ul. Rydygiera 8, 01-793 Warszawa