

1. Przeznaczenie

Torba przeznaczona jest do transportu laptopów o przekątnej do 15,6 cala. Nie jest przystosowana do przewożenia ciężkich ładunków ani jako zabezpieczenie przed upadkami z wysokości.

2. Specyfikacja techniczna

- Materiał: poliester
- Maksymalne obciążenie: 5 kg
- Wyściełana komora na laptopa
- Pasek na ramię z regulacją długości

3. Zasady użytkowania

- Przechowuj laptopa w dedykowanej komorze i zabezpiecz go zamkiem błyskawicznym.
- Nie przeciążaj torby powyżej zalecanego obciążenia.
- Unikaj kontaktu torby z ostrymi przedmiotami.
- Nie przeciążaj torby nadmierną ilością przedmiotów – może to spowodować nacisk na ekran i uszkodzić urządzenie.
- Nie noś torby na jednym ramieniu przez dłuższy czas – może to prowadzić do nierównomiernego obciążenia kręgosłupa.

4. Środki bezpieczeństwa

- Nie wystawiaj torby na długotrwałe działanie wody, mimo wodoodporności materiału.
- W przypadku noszenia cięższego sprzętu, upewnij się, że pasek na ramię jest odpowiednio wyregulowany i zabezpieczony.

5. Konserwacja i czyszczenie

- Czyść wilgotną ściereczką, unikaj stosowania silnych detergentów.
- Nie prać w pralce, nie suszyć mechanicznie.
- Przechowywać w suchym miejscu.

6. Utylizacja

Torba powinna zostać zutyliзована zgodnie z przepisami dotyczącymi odpadów tekstylnych.

1. Purpose

The bag is designed for transporting laptops with a screen size of up to 15.6 inches. It is not suitable for carrying heavy loads or as protection against falls from height.

2. Technical Specifications

- Material: Polyester
- Maximum Load Capacity: 5 kg
- Padded laptop compartment
- Adjustable shoulder strap

3. Usage Guidelines

- Store the laptop in the designated compartment and secure it with the zipper.
- Do not overload the bag beyond the recommended capacity.
- Avoid contact with sharp objects.
- Do not overfill the bag, as excessive pressure may damage the laptop screen.
- Avoid carrying the bag on one shoulder for extended periods to prevent uneven spinal strain.

4. Safety Precautions*

- Do not expose the bag to prolonged water exposure, despite its water-resistant material.
- When carrying heavier equipment, ensure the shoulder strap is properly adjusted and secured.

5. Maintenance and Cleaning

- Clean with a damp cloth; avoid using strong detergents.
- Do not machine wash or tumble dry.
- Store in a dry place.

6. Disposal

The bag should be disposed of in accordance with textile waste regulations.